

FINAL REDUCTION/TRANSMISSION SYSTEM

SERVICE INFORMATION----- 11- 2
TROUBLESHOOTING----- 11- 2
SECONDARY DRIVE/DRIVEN BEVEL GEAR
REMOVAL/INSPECTION/INSTALLATION ----- 11- 3
SECONDARY GEAR SHIMS ADJUSTMENT ----- 11- 8
RIGHT CRANKCASE REMOVAL/INSTALLATION----- 11-10
BEARING REPLACEMENT IN THE RIGHT CRANKCASE ----- 11-12
TRANSMISSION REMOVAL/INSPECTION/INSTALLATION --- 11-17
UPPER SHIFT FORK DISASSEMBLY/ASSEMBLY ----- 11-25
DRIVE SHAFT DISASSEMBLY/ASSEMBLY/INSPECTION ----- 11-26
COUNTERSHAFT DISASSEMBLY/ASSEMBLY/INSPECTION-- 11-27



11.FINAL REDUCTION/ TRANSMISSION SYSTEM



SERVICE INFORMATION

GENERAL INSTRUCTIONS

- The bevel gear and output shaft can be serviced with the engine installed in the frame.

SPECIAL TOOL

Y-type holder	A120E00056
Bearing puller	A120E00037
Bearing drive	A120E00014
Nut wrench	A120E00066

TORQUE VALUES

Crankcase bolt	1.2 kgf-m (12 N-m, 8.6 lbf-ft)	Apply engine oil
Drive bevel gear nut	14 kgf-m (140 N-m, 100.8 lbf-ft)	Apply engine oil
Driven bevel gear nut	14 kgf-m (140 N-m, 100.8 lbf-ft)	Apply engine oil
Stopper lever boss nut	3 kgf-m (30 N-m, 21.6 lbf-ft)	
Stopper lever bolt	2.5 kgf-m (25 N-m, 18 lbf-ft)	
Shift cam stopper plug	4.8 kgf-m (48 N-m, 35 lbf-ft)	
Output shaft bearing nut	11 kgf-m (110 N-m, 79.2 lbf-ft)	Apply engine oil

TROUBLESHOOTING

Engine starts but motorcycle won't move

- Damaged transmission
- Seized or burnt transmission

Oil leaks

- Oil too rich
- Worn or damaged oil seal

SECONDARY DRIVE/DRIVEN BEVEL GEAR REMOVAL/INSPECTION/INSTAL LATION


REMOVAL

Drain engine oil into a clean container. (Refer to the “ENGINE OIL” section in the chapter 3).


Move the engine assembly forward (refer to the “ENGINE REMOVAL” section in the chapter 6) or remove the rear propeller (refer to the “REAR PROPELLER SHAFT DISASSEMBLY/INSPECTION/ASSEMBLY” section in the chapter 13).

Remove the five bolts, then remove the bevel gear case cover.

Remove the two dowel pins and gasket.




Bevel Gear Case Cover



Dowel Pins

Gasket


Using a chisel, unlock the nut in the rear middle joint.




Rear Middle Joint

11.FINAL REDUCTION/ TRANSMISSION SYSTEM


Install the front drive shaft.
Hold universal joint nut by using a suitable bar, then remove the rear propeller shaft nut.



Remove the rear middle joint.



Tap the output shaft by using a rubber hammer, then remove the output shaft, secondary driven bevel gear and shim.



11.FINAL REDUCTION/ TRANSMISSION SYSTEM

Using a chisel, unlock the nut.



Hold the driven pulley by using the special tool (refer to the “DRIVE PULLEY, DRIVE V-BELT AND DRIVEN PULLEY REMOVAL/INSPECTION/INSTALLATION” section in the chapter 10), then remove the nut.

Special tool:

Y-type holder A120E00056

Remove the secondary drive bevel gear.

Remove the shim.



INSPECTION

Check the drive/driven bevel gear teeth for pitting, galling and wear.



11.FINAL REDUCTION/ TRANSMISSION SYSTEM

Inspect the rear middle joint splines for wear or damage.



Inspect the output shaft splines for wear or damage.



INSTALLATION

Install the shim and secondary drive bevel gear.

Holder the driven pulley by using the special tool, then install and tighten the nut to the specified torque.


Torque:

14 kgf-m (140 N-m, 100.8 lbf-ft) Apply oil

Special tool:

Y-type holder A120E00056

Stake the nut with a center punch.



11.FINAL REDUCTION/ TRANSMISSION SYSTEM

Install the output shaft, secondary driven bevel gear and shim

Install the rear middle joint.


Install the front drive shaft.

Hold universal joint nut by using a suitable bar, then install and tighten the rear middle joint nut to the specified torque.

Torque:

14 kgf-m (140 N-m, 100.8 lbf-ft) Apply oil


Remove the front drive shaft.



SECONDARY GEAR SHIMS ADJUSTMENT

Set a dial gauge on the driven bevel gear as shown.

Measure the backlash by turning the rear propeller shaft in each direction, reading the total backlash on the dial gauge. If the backlash is not within specification, the shim must be changed and the backlash should be rechecked until correct. Refer to the chart for appropriate shim thickness.



Bevel gear backlash


Standard: 0.03 - 0.15 mm (0.001 – 0.006 in)

* Adjust the backlash by referring to the chart at the right and using the thickness of the removed shims as a guide.

Backlash	Shim adjustment
Under 0.03 mm (0.001 in)	Decrease shim thickness
0.03 – 0.15 mm (0.001 – 0.006 in)	Correct
Over 0.15 mm (0.006 in)	Increase shim thickness

Drive/Driven bevel gear shims:



- A: 0.6 mm (0.024 in)**
- B: 0.65 mm (0.026 in)**
- C: 0.7 mm (0.028 in)**
- D: 0.75 mm (0.03 in)**
- E: 0.8 mm (0.032 in)**
- F: 0.85 mm (0.034 in)**
- G: 0.9 mm (0.036 in)**
- H: 0.95 mm (0.038 in)**
- I: 1 mm (0.04 in)**
- J: 1.05 mm (0.042 in)**
- K: 1.1 mm (0.044 in)**
- L: 1.15 mm (0.046 in)**



TOOTH CONTACT

After backlash adjustment is carried out, the tooth contact must be checked. Pay attention to the following procedures:

- Remove the driven bevel gear.
- Clean and degrease several teeth of the drive and driven bevel gears.
Apply a coating of machinist's layout dye or paste to several teeth of the driven bevel gear.
- Install the driven bevel gear.
- Rotate the rear propeller shaft several turns in both directions.
- Remove the driven bevel gear and inspect the coated teeth of the drive bevel gear. The tooth contact pattern should be as shown in (1), (2) and (3).
- If tooth contact is found to be correct (example (2)), then to complete installation.



(1): Incorrect (contact at tooth top)

(2): Correct

(3): Incorrect (contact at tooth root)

- If tooth contact is found to be incorrect (examples (1) and (3)), the shim thickness between the drive bevel gear and driven bevel gear must be changed and the tooth contact rechecked until correct.

* Make sure to check the backlash after the tooth contact has been adjusted, since it may have changed. Adjust the tooth contact and backlash until they are both within specification. If the correct tooth contact cannot be maintained when adjusting the backlash, replace the drive and driven bevel gears.


Tooth contact	Drive bevel gear shim adjustment	Driven bevel gear shim adjustment
Contact at tooth top	Increase shim thickness	Increase shim thickness
Contact at tooth root	Decrease shim thickness	Decrease shim thickness

RIGHT CRANKCASE REMOVAL/INSTALLATION

REMOVAL


Remove the cam chain (refer to the “**CAM CHAIN REMOVAL/INSPECTION/INSTALLATION**” section in the chapter 8)
Remove the secondary drive and driven bevel gear (refer to the “**SECONDARY DRIVE/DRIVEN BEVEL GEAR REMOVAL/INSPECTION/INSTALLATION**” section in this chapter).

Remove the stopper plug and washer.




Stopper Plug

Remove the spring and shift cam stopper.



Spring

Remove the four bolts from left crankcase.



11.FINAL REDUCTION/ TRANSMISSION SYSTEM


Remove the fifteen bolts from right crankcase.



Remove the two dowel pins.

INSTALLATION

Apply a light but thorough coating of liquid gasket (Threebond 1215 or equivalent) to all crankcase mating surfaces except the oil passage area.



Dowel Pins

Install the right crankcase and tighten the bolts in a crisscross pattern in 2 or 3 steps.

Torque:

1.2 kgf-m (12 N-m, 8.6 lbf-ft) Apply oil




11.FINAL REDUCTION/ TRANSMISSION SYSTEM

Install and tighten the bolts in a crisscross pattern in 2 or 3 steps


Torque:

1.2 kgf-m (12 N-m, 8.6 lbf-ft) Apply oil



Install the stopper, spring, washer and plug.
Tighten the stopper plug to the specified torque.

Torque: 4.8 kgf-m (48 N-m, 35 lbf-ft)



BEARING REPLACEMENT IN THE RIGHT CRANKCASE


BALANCE SHAFT/COUNTERSHAFT/ PRIMARY DRIVE SHAFT BEARING REPLACEMENT

Remove the balance shaft/countershaft/primary drive shaft bearing by using the special tool.

Special tool:

Bearing puller

A120E00037



11.FINAL REDUCTION/ TRANSMISSION SYSTEM


Install the new balance shaft/countershaft/primary drive shaft bearing by using the special tool.

Special tool:

Bearing driver

A120E00014

Bearing Drive




DRIVE SHAFT BEARING REPLACEMENT

Remove the four bolts and two set plates.

Remove the bearing.

Set Plate



Set Plate

Install the new bearing by using the special tool.


Special tool:

Bearing driver

A120E00014

Install the set plates and tighten the new bolts.


Bearing Driver



11.FINAL REDUCTION/ TRANSMISSION SYSTEM

OUTPUT SHAFT FRONT/REAR BEARING REPLACEMENT

* The output shaft bearings can be replaced when the crankcase is assembly.




REAR SIDE BEARING

Remove the oil seal.

Remove the nut by using the special tool.

Special tool:

Nut wrench A120E00066




Remove the bearing by using the special tool.

Special tool:

Bearing Puller A120E00037

Install the new bearing.



11.FINAL REDUCTION/ TRANSMISSION SYSTEM


Install and tighten the nut to the specified torque by using the special tool.

Torque: 11 kgf-m (110 N-m, 79.2 lb-ft)

Special tool:

Nut wrench A120E00066


Apply clean engine oil to the new oil seal lip then install the oil seal.



FRONT SIDE BEARING

Remove the oil seal.

Remove the snap ring.



Remove the bearing by using the special tool.


Special tool:

Bearing Puller A120E00037

Install the new bearing by using the special tool.

Special tool:


Bearing driver A120E00014



11.FINAL REDUCTION/ TRANSMISSION SYSTEM

Install the snap ring.

Apply clean engine oil to the new oil seal lip
then install the new seal.



Snap Ring


Oil Seal

TRANSMISSION REMOVAL/INSPECTION/ INSTALLATION


REMOVAL

Remove the bolt and then remove the shift arm.

Remove the right crankcase (refer to the “**RIGHT CRANKCASE REMOVAL/INSTALLATION**” section in this chapter)



Remove the shift shaft.




Remove the transmission guide bar.




11.FINAL REDUCTION/ TRANSMISSION SYSTEM

Remove the upper shift fork.
Remove the lower shift fork.



Remove the shift cam.




Shift Cam

Remove the countershaft and driveshaft as an assembly.

Disassemble the countershaft and the driveshaft.

* Keep track of the disassembled parts (gears, washer and clip) by stacking them on a tool or slipping them onto a piece of wire.




Driveshaft Assembly

11.FINAL REDUCTION/ TRANSMISSION SYSTEM


Remove the primary drive shaft.

Primary Drive Shaft



Remove the bolt/washer, then remove the stopper lever and spring.

Spring



Stopper Lever

Bolt/Washer

INSPECTION


Guide bar

Measure the guide bar runout.
Out of specification → Replace.

Service Limit:

Less than 0.03 mm (0.0012 in)

* Do not attempt to straighten a bent guide bar.




Upper shift fork

Inspect the shift fork cam follower and shift fork pawl.

Scoring/beads/wear → Replace a set.

Inspection the spring.


Cracks or damage→ Replace a set..



Lower shift fork


Inspect the shift fork cam follower and shift fork pawl.

Scoring/beads/wear → Replace.



Primary drive shaft

Check the gear teeth for blue discoloration, pitting or wear.



Stopper lever

Check the stopper lever pawl for bends, damage or wear.

Inspect the spring for cracks or damage.



Check the shift cam groove and shift cam gear.

Wear or damage → Replace.



Inspect shift shaft gear.

Damage → Replace.

Inspect shift shaft.

Damage/bends/wear → Replace.

Check the return spring for fatigue or damage.




11.FINAL REDUCTION/ TRANSMISSION SYSTEM

INSTALLATION

Make sure the shaft nut specified torque in the V-belt compartment while holds the stopper lever shaft.

Torque: 3 kgf-m (30 N-m, 21.6 lbf-ft)


Stopper Lever Shaft



Nut

Hook the spring onto the hook part of the stopper lever, squeeze the spring in to the groove of the left crankcase.

Stopper Lever




Spring

Install the washer and a new bolt.
Tighten the bolt to the specified torque while holds the shaft nut in the drive V-belt compartment.

Torque: 2.5 kgf-m (25 N-m, 18 lbf-ft)

Bolt/Washer




Shaft Nut

Stopper Lever


11.FINAL REDUCTION/ TRANSMISSION SYSTEM

Apply clean engine oil to the countershaft assembly, driveshaft assembly and primary drive shaft.

Install the primary drive shaft.
Install the countershaft and drive shaft assemblies as a set into the left crankcase.




Apply clean engine oil to the shift cam, then install the shift cam.



Apply clean engine oil to the gearshift fork, sliding surface and gearshift fork pawl.

Install the lower gearshift fork into the clutch dog (countershaft) and shift cam grooves with its "LDB5" mark facing down.

Install the upper gearshift fork into the clutch dog (countershaft) and shift cam grooves with its "LDB5" mark facing up.



11.FINAL REDUCTION/ TRANSMISSION SYSTEM


Apply clean engine oil to the guide bar,
install the guide bar.



Install the shift shaft.

- *

Align the mark on the shift shaft gear with the mark on the shift cam gear.



Check the transmission operation.
Unsmooth operation → Repair.




UPPER SHIFT FORK DISASSEMBLY/ASSEMBLY

DISASSEMBLY

Remove the upper shift fork (refer to the "TRANSMISSION REMOVAL/INSPECTION/INSTALLATION" section in this chapter)

Remove the snap ring, washer and fork.


Remove the spring, cam pawl and washer.



ASSEMBLY

Install the washer and cam pawl.

* Align the mark on the cam pawl with the mark on the shaft.




Install the spring.

Install the fork.

* Align the mark on the fork with the mark on the shaft.

Install the washer and snap ring.




DRIVE SHAFT DISASSEMBLY/ASSEMBLY/ INSPECTION

DISASSEMBLY


Remove the drive shaft assembly (refer to the “TRANSMISSION REMOVAL/INSPECTION/ INSTALLATION” section in this chapter).

Remove the washer (thick) and reverse gear.

Remove the washer (thin).



ASSEMBLY/INSPECTION



Inspect the gear teeth.
Blue discoloration/pitting/wear → Replace.

Inspect the needle bearing in the reverse gear.
Wear/damage → Replace.

COUNTERSHAFT DISASSEMBLY/ASSEMBLY/ INSPECTION

DISASSEMBLY

Remove the countershaft assembly (refer to the “TRANSMISSION REMOVAL/INSPECTION/ INSTALLATION” section in this chapter).

Remove the washer and high drive gear.




Remove the high/low gear clutch dog

Remove the clip, then remove the washer and low drive gear.

Remove the clip, then remove the stopper wheel.


Remove the clip, then remove reverse gear clutch dog.

Remove the clip, then remove the washer and reverse drive gear.



11.FINAL REDUCTION/ TRANSMISSION SYSTEM

ASSEMBLY/INSPECTION



Inspect the gear teeth.
Blue discoloration/pitting/wear → Replace.

Inspect the mated dogs.
Rounded edges/cracks/missing portions
→ Replace.